




## Cleaning




 **Electrolux**

## Explore 7 Toaster Инструкция по эксплуатации





E7T1-6BP

Quick Guide  
Тостер






A31462603

### Toasting Bread



### Bun Warmer



### Defrost

